



# Sound Test Checklist

1. All doors, door furniture and staircases must be on / in and fitted.
2. All staircases should be fitted and accessible.
3. All windows must be in and sealed correctly including any trickle vents.
4. All skirting boards to be fitted.
5. All walls and floors must be complete (in all plots that are being tested).
6. Is the property and the adjoining property being used / inhabited?  
To carry out the testing access to BOTH properties must be available, and vacant at the time of testing.
7. The site must be quiet during testing and work may need to be stopped in certain areas.
8. 240 volt power needs to be in each room at the sockets, if not can it be made available?
9. Are there any site drawings available?
10. Have carpets been fitted? If they have, they may need to be removed or rolled back to reveal 50% of the floor area in the rooms being tested prior to the engineer attending site.
11. We must inform you that noise levels are used in excess of 110dB(A).